

The TTTM Hanging Kit lets you set up your hammock indoors or wherever you find concrete, brick/stone walls or a sturdy wooden structure.

The kit includes:

- 2 x Hangers
- 2 x Lag Bolts
- 2 x 12mm wall plugs / Fishers
- 2 x Washers
- 1 x Installation Instruction

What you require for set-up:

- 1 x drill
- 1 x 12 mm (1/2 ") drill bit
- 1 x 13 mm wrench or spanner
- 1 x hammer

If you want to install the hanging Kit on wooden structures, please use the screws directly without the wall plugs, as long as your wooden column or beam is strong enough and suitable to drill. Pre drill with a 6mm (1/4 ") before placing the Bolt.

INSTALLATION INSTRUCTIONS

- 1) Try to find the right distance of two walls – usually a distance from 2,7 - 3 m is perfect without the need to add additional rope
- 2) Check the wall by tapping and knocking and see if the wall is sturdy enough and not just a hollow thin layer of ply-wood.
- 3) Choose any height from 1,3 m and higher, depending on the distance of your hangers. Make sure to install the anchors higher if they are further away than 3 m – otherwise you either don't have the 30° angle for your hammock or you will touch the floor ;)
- 4) Drill a hole in concrete or stone wall with a 12 mm (1/2 ") drill bit. Check the length according to the bolt included in the Kit. Clean the hole with a brush or blow residual dust out with a straw
- 5) Gently insert the fisher with the hammer first.
- 6) Insert the lag bolt with the hanger and the washer already threat in, screw the bolt until it is securely tightened.
- 7) Attach your Rope or Moon Strap to the hanger, and use your hammock the way you are used to it. Don't attach the aluminum Carabiner directly to the stainless-steel hanger, because it may damage the Carabiner. Start with gently sitting inside your hammock to see if the hangers are installed safely and secure.